

Digital Photo Frame

(Electronic Photo Album)

3.5" screen



User Guide

DPF35 Ver. 0209

This is a 3.5" screen TFT LCD Digital Photo Frame, that you can view your favourite photos as simple and easy like a photo album in office, or at home; on your working desk or near your bed cupboard. It can display as like a calendar, clock and can serve as an alarm clock. It has passed and meet with our quality assurance. For on-line web technical assistance, please visit <http://lucasind.com/techissues.htm>.



What inside

1. The 3.5" Screen Digital Photo Frame -- the unit
2. Stand
3. Power adapter, AC100~240V, 50/60Hz, DC 5V -500mA
4. USB cord
5. User guide




Power on/off and input

Power on/off

- (1) AC by provided power adapter with USB cord; or
- (2) USB cord linked with computer




Opening Page



Closing Page

Input:

Inserting the SD/MMC memory loaded with photos (in JPG format), the unit will automatically display the photos




Important: Recommend to unplug the connection from AC energy if not intended to play for a long time.



Panel operation

5 intuitive buttons:



- (1) Main -- press short while to play, press longer while to turn off, i.e. stand-by
- (2) Set -- press to go to
 - Calendar display screen
 - Clock display screen
 - Photo slide show
- (3) Previous -- press to go to previous or last photo display, or to increase in selecting time or degree in contrast/brightness
- (4) Next -- press to go to next photo display, or to decrease in selecting time or degree in contrast/brightness
- (5) Menu – press to go to Main Menu for setup, press again, screen menu will become brighter, now available to select



Main Menu (general setup)

Press Menu button (5) go into Main Menu, press (5) again, the screen will become brighter, press Next button (4) or Previous button (3) to select



- Scale Mode, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - Fit Mode
 - Full Mode
 - Origin Mode
 - Pan Scan Mode

After selected, press (5) to confirm & press (1) to resume to play

- Slide Show, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - Manual
 - Auto (Default is 20S; from 00S to 59S; recommended 05S)

After selected, press (5) to confirm & press (1) to resume to play

- Clock Set, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - Year-Month-Day
 - Hour(00)-Minute(00)-Second(00)

After selected, press (5) to confirm & press (1) to resume to play

- Auto On/Off, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - Off <00:00>
 - Disable

After selected, press (5) to confirm & press (1) to resume to play

- Alarm Set, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - Off
 - On <Hour00:Minute00>

After selected, press (5) to confirm & press (1) to resume to play

- Languages, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - English
 - Simplified Chinese

After selected, press (5) to confirm & press (1) to resume to play

- Brightness, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection
 - Brightness <01-11>
- Delete File, press Menu button (5), the menu screen will become brighter, now available to select. Press Next(4) or Previous(3) to move until suitable selection (SUGGEST NOT TO USE THIS FEATURE TO DELETE FILE ON THE CARD TO AVOID ERROR OR OVERSIGHT)
 - Yes
 - No

After selected, press (5) to confirm & press (1) to resume to play

Screen display

There are 3 types. Press each time, there is a change of display screen. Keep staying with the same screen or press Set button (2). Or press Main button (1) to resume back to Photo slide show:

- Calendar display screen
- Clock display screen
- Photo slide show



Technical Specs

Screen	TFT LCD
Size	3.5"
Resolution	320x240
Power (2 modes)	USB or DC5V
Photo	JPG
Built-in memory	8MB
External memory	Memory card : SD/MMC 32MB ~2GB
3 screen display	Photo, Calendar, Clock
Alarm Clock	Available